

INSTALLATION INSTRUCTIONS (Dry Back Vinyl)

Preparations:

1. The surface of the floor must be completely dry. Moisture testing is a mandatory step for subfloor preparations.

A fully functioning HVAC system is required to control both temperature and humidity

2. In a newly constructed building it is necessary to dry the flooring surface for 7 to 14 days prior to application to ensure that no moisture is retained in cement surfaces.

3. Any polish, paint, dirt, etc. must be completely removed from the floor before installation. Dry mop and sweep the entire floor to remove surface sand, soil and debris.

4. Ensure that the floor surface is flat and level. Use a scraper to flatten the floor surface or a putty knife to remove gum and / or labels.

5. Maintain the room temperature above **15°C (59°F)** before installation. Adhesive and flooring product must be kept in the same environment for **at least** 24 hours prior to the installation.

Installation

1. Check that all application products are of the same batch / lot number.

2. Find the exact center of the floor by marking vertical and horizontal lines across the floor.

3. Measure the squareness of the marked lines, and then start

applying adhesives on the first quarter of the marked floor space.

4. Work on small portions of the floor at a time, and apply adhesives. Optimum usage of adhesive is 0.3 to 0.45 kg per square meter.
5. Lay the flooring product approximately 20 to 30 minutes after applying adhesive.
6. Keep a distance of 1 mm from the wall and the edge of the flooring product. Press product down firmly so that the product lies flat on the ground.
7. As the adhesives are highly flammable, avoid any contact with sparks or open flames.
8. As the adhesives dry quickly, remove excess adhesive immediately by using alcohol or alkali water.

For installation guidelines and technical questions not covered in this installation guide, please contact your dealer for additional information.